



T260

Walk-Behind Scrubber

COMMON PARTS & CONSUMABLES

Only genuine Tennant parts can ensure peak performance for the life of your equipment.

Serial # _____

Brushes

- Easy installation helps reduce machine downtime.
- Optimal operation with Tennant machines, maximizing cleaning effectiveness in one pass.

PART DESCRIPTION	PART #
Polpropylene Scrub Brush	CN5006244

Batteries

PART DESCRIPTION	PART #
135AH, 12V, GEL Battery, 2 required	1251238
Off-board Battery Charger	CN5006264
Power Cord	CN5004235

Squeegee

- Tennant offers three types of squeegee materials to best suit your needs.
 - Premium Linatex® rubber exhibits outstanding strength and resistance to cutting and tearing.
 - Chemical-resistant urethane has a long service life; well suited for use with organic and petroleum-based oils.
 - Economy Gum Rubber is cost-effective option for smooth, indoor floors, made of a combination of natural material and fillers.

	PART DESCRIPTION	PART #
FRONT	Linatex® Squeegee	1203954
	Urethane Squeegee	1215611
	Gum Squeegee	1215612
REAR	Linatex® Squeegee	1203953
	Urthane Squeegee	1215609
	Gum Squeegee	1215610

Pricing & Ordering

Contact Tennant Customer Service by phone at **1800 226 843** or by mail:
contactus@tennantco.com or order through **MyTennant** at **www.tennantco.com.au**

Prices and programs subject to change without notice. ©2025 The Tennant Company. All rights reserved. Rev 1/2025

General Maintenance

- Tennant True® parts are designed to fit your Tennant machine, helping achieve better cleaning performance and reducing machine downtime.

PART DESCRIPTION	PART #
Hose, Drain, Recovery Tank	CN5002833
Hose Assy, Recvy	CN5002836
Waste Water Filter Box Cover	CN5005723
Waste Water Strainer	CN5005711
Splash Guard	CN5006241
100A Fuse	CN5001636
5A Protector (with Waterproof Cap)	CN5001643
25A Protector (Including Waterproof Cap)	CN5001647
30A Protector (with Waterproof Cap)	CN5001644
Electrical Contactor	CN5001703
Squeegee Caster Wheel	630477
Estop Switch with Key	CN5001546
Key Only	CN5001519

Pricing & Ordering

Contact Tennant Customer Service by phone at **1800 226 843** or by mail:
contactus@tennantco.com or order through **MyTennant** at **www.tennantco.com.au**
Prices and programs subject to change without notice. ©2025 The Tennant Company. All rights reserved. Rev 1/2025